

Bienfang®

Framing Products

Bienfang® Vacuum Press® 3648H, 4468H and 5298H

Trouble-Shooting Guide



CONTENTS

Overview	3
Heat Related Malfunctions	
Run away heat condition with heat control off	4
Press runs hotter than set temperature	6
No heat or press runs cold	7
Temperature readout always reads 35-50 deg F	8
Temperature readout always reads over 300 deg F	8
Higher temperatures not obtainable	9
Control/ Display Related Malfunctions	
Controller self-diagnostics	10
Continuously erratic display from power up	10
Display fine on power up but become erratic after operation	11
Controller resets itself during cycles	11
Display blanking out	11
No display at all	12
Programming malfunctions	12
Button or buttons don't operate	12
Vacuum Related Malfunctions	
Pump won't turn on	13
Pump won't turn off	14
Intermittent pump operation	14
Solenoid won't open or close	15
Technical Data Sheet	
Heater resistance	16
Parallel combination of heaters	16
Sensor resistance at various temperatures	17
Solid-state relay operational voltages	17
Picture References	
Control Panel	6
Solid-state relay	18
View of access panel	18
Power Board	19

OVERVIEW

Please read the entire owners manual and fully understand the proper operating procedures before continuing the trouble-shooting guide.

Each Bienfang® Vacuum Press is fully assembled, calibrated, and tested at the factory to pull a high level of vacuum in a minimum amount of time. Once passed by the Quality Control Department, the completely tested press and pump are packaged and shipped together to ensure that each customer receives a complete and tested unit.

However, during shipping and uncrating, the alignment of the top and the base of the press may be altered. To ensure proper alignment of the press, refer to page 5 of the Owner's Manual for instructions.

If problems persist, or questions arise after referring to this guide, please contact Bienfang's Technical Service Department at 1-888-240-6021.

HEAT RELATED MALFUNCTIONS

Run Away Heat Condition With Heat Control Off

Possible Causes:

- Sensor or sensor assembly
- Solid-state relay
- Mis-wired power board assembly (if new installation)
- Mis-wired control board assembly (if new installation)

*This section is to be used in the case of presses that experience a severe runaway heat condition. Use this section **ONLY** if the press continues to heat up even with the heat control indicator **OFF**.*

A faulty sensor or a sensor that is pulled away from the platen would cause a run away condition, however, the rate of change indicated on the temperature display can provide clues as to whether or not a sensor has pulled away. The display would still indicate rising temperature although not as intensely.

A bad solid-state relay would also cause the heat to run away. The type of relays used in the Vacuum Presses normally fail in the “on” state. The inline heater thermostat switches will break the heater connection after 350°F is reached, but then reset after the temperature drops.

The power board receives an “on” signal from the controller that turns on the solid-state relay with 1 transistor. If this transistor is bad, it is possible that the relay will always be on, however, this transistor would normally fail in the “off” state leaving the power board as an unlikely cause of failure in most cases.

The controller measures the temperature from the sensor, then decides if the heaters need to be “on” or “off” based on the set temperature when in heat control mode. If the sensor input circuitry is faulty it can be diagnosed by disconnecting the sensor and reading the display as indicated below. The controller sends 1 signal to the power board to turn “on” and “off” the heaters. If this signal is faulty, it can be diagnosed by disconnecting the controller altogether as outlined.

Non Intrusive Actions:

1. Power up cold press.
2. Press “heat off” button.
3. Verify heat control “led” is off.
4. Does the temperature read out indicate room temperature, then increase at a very slow rate as compared to the actual platen temperature?
If yes- refer to “Press runs hotter than set temperature” section
If no- continue

Does the temperature read out indicate room temperature then follow rising temperature rapidly?

If yes- sensor is OK.

If no- proceed to Intrusive Actions, Step 5.

Intrusive Actions:

5. With power off, remove control panel from housing.
6. Disconnect ribbon cable from control panel assembly.
7. Power up press.
8. Does press heat up?
 - If yes- control panel is OK, proceed to Step 9.
 - If no- control panel or ribbon cable is faulty, replace both.
9. With power off, reconnect ribbon cable.
10. Disconnect sensor harness from back of controller assembly.
11. Turn power on.
12. Use a paper clip or a piece of metal to short the two pins on the controller sensor connector together.
13. Does the display read less than 50°F when shorted and over 300°F when opened?
 - If yes- if sensor was OK from step 5, then continue. Otherwise, stop and check or replace sensor assembly.
 - If no- replace control panel assembly.
14. With power off, disconnect the wire from power board labeled “Coil+”
15. Turn power on.
16. Does press still heat up?
 - If yes- solid-state relay is faulty, replace.
 - If no- power board or ribbon cable is faulty, replace both.
17. With power off, reconnect “Coil+” wire.

Press Runs Hotter Than Set Temperature

Possible causes:

- Sensor or sensor assembly
- Control board assembly

*This section is to used for presses that experience hotter than normal operating temperatures. **DO NOT** use this section for run-away temperature conditions.*


A faulty sensor, or a sensor that has pulled away from the platen will cause the temperature to run higher than normal. If the sensor is not firmly mounted to the platen, the press will run hot. A controller with a bad sensor input circuit will also cause faulty temperature control.

Non-Intrusive Actions:

1. Power up cold press.
2. Press “heat on” button and set temperature for 200°F.
3. Does the temperature read out indicate room temperature, then increase at a very slow rate as compared to the actual platen temperature?
If yes- proceed to Step 4.
Does the temperature read out indicate room temperature, then follow rising temperature rapidly?
If yes- sensor is probably OK.
If no- proceed to Step 4.

Intrusive Actions:

4. With power “off”, remove control panel from housing.
5. Disconnect sensor harness from back of controller assembly.
6. Turn power “on”.
7. Use a paper clip, or a piece of metal to short the two pins on the controller sensor connector together.
8. Does display read less than 50°F when shorted and over 300°F when opened?
If yes- if sensor was Ok from Step 4, then continue. Otherwise, stop and check or replace sensor assembly.
If no- replace control panel assembly.



Pictured above is the control panel. The hose goes into the bottom valve. The sensor and the ribbon cable are also pictured.

No Heat Or Press Runs Cold

Possible Causes:

- Sensor or sensor assembly
- Control board assembly
- Power board assembly
- Mis-wired (only if new installation)
- Solid-state relay
- Heater safety thermostats

This section is to be used for presses that will not heat up after the “heat on” indicator has been verified “on” and a valid set temperature has been entered.

A faulty sensor or sensor harness that has become opened will cause the controller to think that the press is too hot, therefore, never turning on the heaters. This can be easily diagnosed by interpreting the temperature display.

A controller with a bad sensor input circuit or a bad heater control output circuit will also cause faulty or no temperature control.

The inline heater thermostats may be stuck open not allowing any power to the heaters if they are wired in series. If they are wired in parallel, then only ½ of the press will get hot.

Intrusive Actions:

1. With power off, remove control panel from housing.
2. Disconnect sensor harness from back of controller assembly.
3. Turn power “on”.
4. Use paper clip or a piece of metal to short the two pins on the controller sensor connector together.
5. Does display read less than 50°F when shorted and over 300°F when opened?
If yes- continue to Step 6.
If no- replace control panel assembly.
6. With the sensor connected, does the display read room temperature at cold start?
If yes- continue to Step 7.
If no- check and/or replace sensor assembly.
7. Turn power to the “press off” and replace the control panel assembly.
8. Disconnect “Coil-” wire and connect it to extra ground lug on power board, using tacking iron ground lug if necessary.
9. Turn power “on”.
10. Does press get hot?
If yes- the heaters and the solid-state relay are good. Replace power board or control panel and/or ribbon cable.
If no- most likely the solid-state relay is bad. Replace it. There is still however a chance that the heater have an open thermostat.

Temperature Readout Always Reads 35-50 deg F

Possible Causes:

- Sensor or sensor assembly
- Control board assembly

A shorted sensor or sensor harness will always cause this malfunction. A faulty controller may also cause this problem but can be easily and safely diagnosed.

Intrusive Actions:

1. Remove control panel from housing. With power “off”.
2. Disconnect sensor harness from back of controller assembly.
3. Turn power “on”.
4. Use paper clip or a piece of metal to short the two pins on the controller sensor connector together.
5. Does display read less than 50°F when shorted and over 300°F when opened?
If yes- check and/or replace sensor
If no- replace control panel assembly

Temperature Readout Always Reads Over 300°F

Possible Causes:

- Sensor or sensor assembly
- Control board assembly

An open sensor or sensor harness will always cause this malfunction. A faulty controller may also cause this problem, but can be easily and safely diagnosed.

Intrusive Actions:

1. With power off, remove control panel from housing.
2. Disconnect sensor harness from back of controller assembly.
3. Turn power “on”.
4. Use a paper clip or a piece of metal to short the two pins on the controller sensor connector together.
5. Does display read less than 50°F when shorted and over 300°F when opened?
If yes- check and/or replace sensor.
If no- replace control panel assembly.

Higher Temperatures Are Not Obtainable

Possible Causes:

-Inline heater thermostats

This section should only be used when the press seems to operate normally at lower temperatures but not at higher temperatures.

Intrusive Actions:

1. With power off, remove control panel from housing.
2. Disconnect sensor harness from back of controller assembly.
3. Turn power "on".
4. Use a paper clip or a piece of metal to short the two pins on the controller sensor connector together.
5. Does display read less than 50°F when shorted and over 300°F when opened?
If yes- continue to Step 6.
If no- replace control panel assembly
6. Repeat Step 5 and keep short in place.
7. Does the press seem to attain higher temperature than previously attainable with short in place?
If yes- continue to Step 8.
If no- chances are that the heaters or heat thermostat are bad. Replace them.
8. After a high temperature has been reached, remove short and re-connect sensor harness.
9. Does the temperature display read a higher temperature than the maximum previously attainable?
If yes- sensor is probably OK.
If no- check and/or replace sensor harness.

CONTROL/ DISPLAY RELATED MALFUNCTIONS

Controller Self Diagnostics

1. Turn press “off”.
2. Hold down enter key.
3. Turn press “on”.
4. If displays a “C” and a number, replace the control panel.

Note: The numbers in the temperature and vacuum display are the current A/D values being read by the controller and don't really provide useful information.

5. After the “PASS” message goes away, the controller is waiting in the ‘Button Test Mode’.
6. It will display a “0” until a button is pressed and held down.
7. Each button has a corresponding number (1-23).
8. Each time a button is released the “0” should re-appear.
9. If the “0” does not appear, the button is stuck and should be replaced.
10. Press the “Start and Enter” buttons at the same time to exit the button test and enter the ‘Power on defaults’ section.
11. The display will read 1-d, 1-e, 2-d, or 2-e.
12. 1-d stands for option 1 disabled. 1-e stands for option 1 enabled. This option determines whether the pump shuts off or stays on at the end of a program. To toggle between enable and disable, press “manual on/off” button.
13. 2-d stands for option 2 disabled. 2-e stands for option 2 enabled. This option sets the English or metric power on default. To toggle between, press “English/Metric” button.
14. To proceed to the auto program feature, press “program” button. The display will read “ a p”.
15. Pressing the “program” button will load the 5 default programs into memory.

Continuously Erratic Display From Power Up

Possible Causes:

-Controller Assembly

*This section is to be used only when the controller shows erratic display initially from power up state or if the display does not always come up. **DO NOT** use this section if the controller seems OK then goes haywire during operation, please refer to next section.*

Non-Intrusive Actions:

1. Turn press “on”.
2. Does the display read normal?
If yes- repeat Step 1 and/or refer to next section
If no- replace control assembly

Display Fine On Power But Becomes Erratic After Operation Controller Resets Itself During Cycles Display Blanking Out

Possible Causes:

- Controller assembly
- Poor ground connections
- Loose ribbon cable or power connection to power board

This section is to be used only when the controller operates normally then goes haywire during operation.

Because of the grounding method used to ground the heater platen and the high voltage running through the heaters, there exists a sizable potential for arcing to occur between the heater platen and the press frame. If, or when the arc does occur, large EMI spikes travel through the system causing the controller's microprocessor to become lost. It is important to note that arcing can only occur during a hot cycle or during pump cycling.

It is also possible that the controller itself has an onboard heat problem or prom malfunction causing failures at certain points in its operation.

A small interruption in power to the controller assembly during operation will surely cause the operation to become erratic. Small interruptions will cause a partial reset of the controller's processor and are most likely caused by a poor connection or intermittent short in the ribbon cable.

Non-Intrusive Actions:

1. Turn press "on".
2. Does the display read normal?
If yes- proceed to Step 3.
If no- refer back to "Continuously Erratic Display from power up".
3. Run a cold cycle for 10 minutes or so with the vacuum pump off.
4. Does the display read normal?
If yes- proceed to Step 5.
If no- replace controller assembly and ribbon cable

Intrusive Actions:

5. Run a hot cycle for approx. 5 minutes.
6. Open and close the lid during this 5 minutes, also turn pump "on" and "off" several times.
7. Does the display read normal?
If yes- proceed to Step 8.
If no- there is a grounding problem, check the platen and controller housing grounds and then repeat Step 5.
8. Remove controller from housing.
9. Repeat Steps 3 & 4.

No Display At All

Possible Causes:

- Controller assembly
- Poor ribbon cable or power connections
- Power board
- Circuit breaker

This section is to be used only if there are no signs of life at all on the displays of the controller. If on power up, there are any flashes of leads or an audible “beep”, refer to section on “Continuously erratic display from power up”.

The power board has a 5 volt fuse that may be blown. If any lights or “beeps” occur, then the power board can be ruled out as the cause of the malfunction and the controller is most likely at fault.

Intrusive Actions:

1. With power off, remove control panel from housing.
2. Check ribbon cable connection and turn power “on”.
3. Is display still dead?
 - If yes- proceed to Step 4.
 - If no- replace ribbon cable.
4. Plug lamp or other device into tacking iron outlet.
5. Does the device operate?
 - If yes- circuit breaker and power connections are OK. Proceed to Step 6.
 - If no- circuit breaker or power connections are faulty. Check connections and replace breaker if necessary.
6. Either the controller assembly or power board is bad. Replace controller first.

Programming Malfunctions Button Or Buttons Don't Operate

Possible Causes:

- Controller assembly

This section is to be used only if the controller operates correctly during manual mode but not while running a program, or if there is a stuck button or an inoperable one.

Non-Intrusive Actions:

1. Run controller self diagnostics- directions on page 10.
2. Does controller pass the button test and display “PASS”?
 - If yes- refer to owners manual. Replace controller if problem persists.
 - If no- replace controller assembly.

VACUUM RELATED MALFUNCTIONS

Pump Won't Turn On

Possible Causes:

- Pump
- Bad connection
- Power board
- Controller assembly

This section is to be used only if the controller has power and operates correctly and if a program with vacuum commanded on has been attempted and pump still won't turn on.

Non-Intrusive Actions:

1. Disconnect pump from power outlet.
2. Turn press "on".
3. Press manual "on/off" button on control panel several times while listening for clicking noise near the power board.
4. Does there appear to be a clicking noise?
 - If yes- controller and ribbon cable are OK. Pump, connections, or power board is bad. Proceed to Step 6.
 - If no- proceed to Step 6.

Intrusive Actions:

5. Plug vacuum pump into outlet.
6. With power off, disconnect MTR+ wire from power board and connect to one of the L1 connections. Disconnect tacking iron outlet if necessary.
7. Turn power "on".
8. Does pump turn "on"?
 - If yes- pump is OK, check pump outlet wiring. Proceed to Step 9.
 - If no- check power connections to press and/or replace pump.
9. Either the controller or power board is bad. Replace power board first.

*Note: If the tacking iron outlet is the same as the pump outlet, then use it instead of Steps 6 & 7 to determine whether the pump is OK.

Pump Won't Turn Off Intermittent Pump Operation

Possible Causes:

- Power board
- Controller assembly
- Wiring

The pump operates via 1 signal from the control board. This signal turns “on” the pump relay located on the power board. A faulty power board is most likely the cause.

Non-Intrusive Actions:

1. Run controller diagnostics.
2. Check manual “on/off” button. Make sure it is not stuck.
3. If button test fails, replace controller.

Intrusive Actions:

4. With power off, disconnect ribbon cable from control panel.
5. Turn power back “on”.
6. Does pump shut off?
 - If yes- controller or ribbon cable is bad. Replace both.
 - If no- check pump outlet wiring. If OK, replace power board.

Solenoid Won't Open Or Close

Possible Causes:

- Power board
- Controller assembly
- Wiring

This section is to be used only if the controller and pump are working properly.

The solenoid valve is normally open in the de-energized state and operates via 1 signal from the control board. This signal turns on the solenoid power transistor located on the power board.

Non-Intrusive Actions:

1. Disconnect pump from outlet.
2. Press manual "on/off" button several times and listen for clicking noise near solenoid.
3. Can clicking noise be heard?
If yes- the wiring, power board, and controller are fine. Replace solenoid.
If no- proceed to Step 4.

Intrusive Actions:

4. With power off, disconnect solenoid wire at power board labeled SOL-.
5. Connect it to the ground terminal. Use tacking iron outlet, ground if necessary.
6. Does solenoid click?
If yes- either the controller, ribbon cable, or power board is bad. Replace power board first.
If no- solenoid or solenoid wiring is bad. Replace both.

TECHNICAL DATA SHEET

Heater Resistance

With the unit unplugged from the wall supply, the resistance of the heaters can be measured. Individual heaters will measure according to the chart below.

Vacuum Press Model Number	Individual Heater Resistance
3444	31.2 ohms +/- 7%
3648H	50.0 ohms +/- 7%
4468	31.2 ohms +/- 7%
5298 (Left or Right)	27.4 ohms +/- 7%
5298 (Center)	34.4 ohms +/- 7%

Parallel Combination of Heaters

To measure the overall parallel combination of the heaters in the press, disconnect the heater terminals from the power board and solid-state relay. Refer to the chart below.

Vacuum Press Model Number	Parallel Combination
3444 (only 1 heater)	31.2 ohms +/- 7%
3648H	25.8 ohms +/- 10%
4468 (2 heaters)	15.6 ohms +/- 10%
5298 (3 heaters)	9.8 ohms +/- 12%

Sensor Resistance at Various Temperatures

Use the following chart to look up the sensor resistance at various temperatures with the sensor unplugged from the controller.

Temperature	Resistance
20° C (68° F)	2000 ohms +/- 5
30° C (86° F)	2075 ohms +/- 6
40° C (104° F)	2153 ohms +/- 7
50° C (122° F)	2231 ohms +/- 7
60° C (140° F)	2312 ohms +/- 9
70° C (158° F)	2394 ohms +/- 10
80° C (176° F)	2478 ohms +/- 12
90° C (194° F)	2564 ohms +/- 14
100° C (212° F)	2651 ohms +/- 16
110° C (230° F)	2740 ohms +/- 18
120° C (248° F)	2831 ohms +/- 20
130° C (266° F)	2924 ohms +/- 22
140° C (284° F)	3018 ohms +/- 24
150° C (302° F)	3114 ohms +/- 25

Solid-State Relay Operational Voltages

Relay input side (marked “coil+” and “coil –” on power board)

Heat “on”= 12 vdc +/- 1.2 volts

Heat “off”= 0 vdc +/- 1 volt

Relay output side (measured from across the relay)


Heat “on”= 0 vac +/- 5 vac

Heat “off”= 220 vac +/- 20 volts


Picture References



Pictured above is the solid-state relay. It is mounted beneath the diaphragm on the far right side of the access panel.



Pictured above is the access panel. Located from left to right- solenoid, power board, distribution block, and solid-state relay.



Pictured above is the power board.